






CVFVR8437-ASSEMBLY INSTRUCTIONS

NOT: REQUIRED ANTI TIP KIT BEFORE USING THE PRODUCT




NOT SUPPLIED


PARTS LIST

No	Hardware List		Q'ty	A x 1	B x 2	C x 2	N x 1
1		Bolt 1/4"x55mm	8				
2		Lock washer 1/4"	8				
3		Flat washer 1/4"*19*1.5mm	8				
4		Allen key 4mm	1				


Step 1



Step 2







NOT: REQUIRED ANTI TIP KIT BEFORE USING THE PRODUCT




NOT SUPPLIED


PARTS LIST

No	Hardware List		Q'ty	A x 1	B x 2	C x 2	N x 1
1		Bolt 1/4"x55mm	8				
2		Lock washer 1/4"	8				
3		Flat washer 1/4"*19*1.5mm	8				
4		Allen key 4mm	1				

Step 3



Step 4



FINISH

Leveler can be adjusted as necessary for the dresser balance