













ASSEMBLY INSTRUCTION


CVFNR4595

PARTS LIST					HARDWARE LIST			
S.NO.	DESCRIPTION			QTY	S.NO.	DESCRIPTION		QTY
A	A1		TOPS	2	D		ALLEN BOLT (6X16mm)	24
	A2							
B	B1		BASE	2	E		ALLEN WASHER (6X16mm)	24
	B2							
C	C1		LEGS	4	F		ALLEN KEY (4mm)	1
	C2							
	C3							
	C4							


STEP 1. Put the Top upside down on clean surface & screw the legs as shown in the image.




STEP 2. Put the second top upside down, & screw as shown in the image.



STEP 3. Now assemble the remaining Legs, tighten the bolts for all the legs.



STEP 4. Final Image.



NOTE- Leveller are provided at bottom to balance the product on uneven surface.