


7564 Lennox Sectional | Components & Configurations


Sectionals

Components


LAF = Left-Arm-Facing
RAF = Right-Arm-Facing




-37
LAF Sofa




-38
RAF Sofa




-33
LAF Corner Sofa




-34
RAF Corner Sofa




-29
Armless Loveseat




-27
LAF Loveseat




-28
RAF Loveseat




-255
LAF Angled Chaise




-265
RAF Angled Chaise




-231
Corner Chair




-23
Full Wedge




-19
Armless Chair




-17
LAF Chair



-18
RAF Chair



-25
LAF Chaise



-6
RAF Chaise

Scale 1/4"=1'






Dimensions are in inches and are subject to variance.
© Flexsteel Industries, Inc. 6/22
FLX-FR7564-CC-PP

FLEXSTEEL®

7564 Lennox Sectional | Components & Configurations

Sectionals

Sample Configurations



Scale 1/4"=1'

Dimensions are in inches and are subject to variance.
© Flexsteel Industries, Inc. 6/22
FLX-FR7564-CC-PP

FLEXSTEEL®