


homestyles®

6694-831

Table

IMPORTANT


Carefully remove all the parts from the carton and place them individually on a soft cloth to prevent scratches or other damage.



Carefully and strictly follow these assembly instructions to ensure a completed product as designed.

This product is made of aluminum. Do not use power tools above 8 volts to assemble and only tighten bolts until snug. Over tightening can damage the aluminum.

Part List




A.
Top
1 pc.


B.
Side
2 pcs.

C.
Side
2 pcs.

Hardware List



Small Hex Wrench
1 pc.



Hex Wrench
1 pc.



01
Head Cap Bolt
20 pcs. (+1 extra)



02
Spring Washer
20 pcs. (+1 extra)



03
Flat Washer
20 pcs. (+1 extra)

Tool(s) required for assembly: Level

homestyles Customer Service: www.homestylesfurniture.com,
servicedesk@homestylesfurniture.com, 888-680-7460

Assembly Instructions 2/5

IMPORTANT

- Use a soft cloth between these parts and the floor.
- Do not use power tools above 8 volts to assemble.
- Do not tighten all the bolts until each part is properly assembled.
- Keep Hex Wrench as the bolts may need to be tightened in the future.

STEP 1

Turn Top (A) upside down on a soft cloth.

Attach Side (B) to Top (A).





Figure 1



STEP 2

Insert 4 pcs. of **01, 02** and **03** into pre-drilled holes of Side (B), tightening **01** only halfway.
(See Figure 1)

Assembly Instructions 3/5

STEP 3

Attach Side (B) to unit.





STEP 4

Insert 4 pcs. of **01, 02** and **03** into pre-drilled holes of Side (B), tightening **01** only halfway.

Assembly Instructions 4/5

STEP 5

Attach Side (C) to unit.



STEP 6



Insert 6 pcs. of **01, 02** and **03** into pre-drilled holes of Side (C), tightening **01** only halfway.
(See Figure 2)

Assembly Instructions 5/5

STEP 7

Attach Side (C) to unit with 6 pcs. of **01**, **02** and **03**, tightening **01** only halfway.

Tighten all **01**.



STEP 8

Turn over unit to its upright position.

Level table by adjusting the adjustable levelers on bottom of legs.
(See Figure 3)




Figure 3

CARE INSTRUCTIONS

NEVER

allow liquids to remain on furniture.

Absorption causes parts to warp and split and finishes to delaminate.

NEVER

use glass cleaners on finished furniture. Ammonia chemically attacks the finish.



Do not use power tools above 8 volts to assemble.

PREVENT CRACKING



Do not write directly on surface.

PREVENT MARKING



Do not use rubber based placemats.

PREVENT DISCOLORING



Do not place hot objects on surface.

PREVENT FINISH DAMAGE




Do not use commercial waxes and polishes.

PREVENT YELLOWING

CLEAN

with a soft cloth moistened in lukewarm soap and water.
Buff with a dry clean cloth.



homestyles will provide replacements free of charge for missing or damaged parts within 2 years of purchase. Digital images of the defective parts may be required. If the product was not purchased from an authorized retailer, **homestyles** is under no obligation to provide replacement parts. Parts are not available for fully assembled items nor are parts available for sale. Replacements for missing or damaged parts may be requested via contact info below.

homestyles Customer Service: www.homestylesfurniture.com,
servicedesk@homestylesfurniture.com, 888-680-7460