



ASSEMBLY INSTRUCTIONS

ITEM: MV-5962-75412-81 MISSION BAY SIDE CHAIR

Please read all instructions carefully before starting the assembly process. Please be sure to unpack carefully as small parts may have come loose during travel from paradise. Helpful tip--do not fully tighten bolts until assembly is complete. It will make assembly easier


HARDWARE PACK

NO	DRAWING	DESCRIPTION	SIZE	Q'ty
A		Hexagonal bolt	$\frac{5}{16}$ " $\times$ 1- $\frac{3}{4}$ "	2pcs
B		Hexagonal bolt	$\frac{5}{16}$ " $\times$ 3- $\frac{1}{2}$ "	4pcs
C		Lock washer	$\frac{5}{16}$ " $\times$ 12 $\times$ 3	10pcs
D		Flat washer	$\frac{5}{16}$ " $\times$ 19 $\times$ 2	10pcs
E		Nut	$\frac{5}{16}$ " $\times$ 12	4pcs
F		Wrench	12mm	1pc


PART LIST

NO	DRAWING	DESCRIPTION	Q'ty
①		Chair back	1pc
②		Seat Cushion	1pc
③		Front leg	2pcs


Step 3




Step 1



Step 2



Complete



Note: Anti-tip restraint is provided
Please follow the instructions enclosed with the pack



ASSEMBLY INSTRUCTIONS

ITEM: MV-5962-75412-81 MISSION BAY SIDE CHAIR


Please read all instructions carefully before starting the assembly process. Please be sure to unpack carefully as small parts may have come loose during travel from paradise. Helpful tip--do not fully tighten bolts until assembly is complete. It will make assembly easier

PLEASE READ THESE INSTRUCTIONS PRIOR TO ASSEMBLING THE CHAIRS CHAIR LEVELING INSTRUCTION SUPPLEMENT

Chair leveling procedures:

To make the assembly process easy and efficient, please read the entire instruction sheet prior to assembling of the chair. Make sure all hardware listed is included. To properly assemble the chair, none of the bolts should be fully tightened until all components are attached to the chair. This will allow an opportunity to level the chair and prevent any unnecessary "rocking".

- 1.Place the loosely assembled chair on a hard flat surface.
- 2.Apply gentle downward pressure on the seat. This step eliminates rocking and ensures the chair to be level.
- 3.Once the chair is level, tighten all bolts and nuts.



Note:

Most floors have slight irregularities that can affect chair leveling. If your chair is uneven when placed in its desired location, perform the following steps:

Loosen front legs to finger tight.

Extend both front legs upward to their fullest length.

Gently push downward on the front edge of the seat until all four legs rest on the floor.

- 4.Re-tighten all bolts and nuts.

Note:Anti-tip restraint is provided

Please follow the instructions enclosed with the pack