



ASSEMBLY INSTRUCTIONS

ITEM: MV-5962-80116-05 Coral Rd End Table

Please read all instructions carefully before starting the assembly process. Please be sure to unpack carefully as small parts may have come loose during travel from paradise. Helpful tip--do not fully tighten bolts until assembly is complete. It will make assembly easier.


HARDWARE PACK

NO.	DRAWING	DESCRIPTION	SIZE	Q'TY
1		ANTI-TIP KIT		1 PC


TOOL REQUIRED

DRAWING	DESCRIPTION
	PHILIP HEAD SCREWDRIVER (NOT INCLUDED IN PACKAGED)

An anti-tip kit is included. Installing it is highly recommended for safety reasons.



Tipping Restraint



Adjust the levelers if needed to level the table on an uneven floor.

Note: Anti-tip restraint is provided.
Please follow the instructions enclosed with the pack.



ASSEMBLY INSTRUCTIONS

ITEM: MV-5962-80116-05 Coral Rd End Table


Please read all instructions carefully before starting the assembly process. Please be sure to unpack carefully as small parts may have come loose during travel from paradise. Helpful tip--do not fully tighten bolts until assembly is complete. It will make assembly easier.

Instruction for hinge adjustments (If necessary)

Tools Need:



- Phillips head screwdriver

Note: Avoid using a power drill, as it's very easy to strip the screws or crack the wood.



Depth Alignment:

To adjust the gap between the door and frame, loosen the rear locking screw, turn it Clockwise to move the door inward or Counter-clockwise for outward, then re-tighten to secure.







ASSEMBLY INSTRUCTIONS




ITEM: MV-5962-80116-05 Coral Rd End Table

Please read all instructions carefully before starting the assembly process. Please be sure to unpack carefully as small parts may have come loose during travel from paradise. Helpful tip--do not fully tighten bolts until assembly is complete. It will make assembly easier.



Side-to-Side Alignment:

To fix gaps or overlapping doors, turn the screw clockwise to shift the door right, or counter-clockwise to shift it left.



Vertical Alignment:

For sagging or uneven doors, turn the screw clockwise to raise the door or counter-clockwise to lower it.

