









DC 605-Fabric Desk Chair Assembly Instructions



Parker Living®
A Division of Parker House




A x1	B x1		C R x1	C L x1	D x1	E x1	F x5	
								
G x3	H x2	J x3	K xR x1	K xL x1	M x1	N x1	O x1	
								
M8X25mm	M8X45mm						USB-C charger optional. Do NOT use to charge external devices.	

STEP 1 	STEP 2 	STEP 3 
STEP 4 	STEP 5 	STEP 6 

1. Press the ON button briefly.
 - The full-body massage mode will start automatically.

2. Press the OFF button to turn off the power.
 - Equipped with a safety timer function, it will automatically stop after 16 minutes of operation.
 - When stopping, the massage balls will return to their starting position.





WARNING: The USB-C port is intended only for charging the chair's internal battery. Do not use it to charge phones, tablets, laptops, or any other electronic devices. Doing so may result in improper operation or damage.


Do not use or operate the chair while it is charging.



Flip-up arms



1. When using the footrest, first pull it forward, then flip it over.
2. After use, flip it back in the opposite direction and store it in its original place.



1. The seat & backrest can be adjusted to your desired angle for use.

2. Push the handle to adjust the seat height to desired height. Pull out the handle, lean on the back to recline. Reclining angle can reach up to 135 degrees and be adjusted to any angle as needed.

3. Pull in the handle to lock reclining.

01 Usage and Storage Methods

Usage Instructions

1. Please fix it in a stable position.

- The lumbar support can be adjusted according to the required height.

2. Please press the ON button briefly.

- The full-body massage mode will start automatically.

3. Press the OFF button to turn off the power.

- Equipped with a safety timer function, it will automatically stop after 15 minutes of operation.
- When stopping, the massage balls will return to their starting position.

Storage Instructions

1. Please store it in a cool and well-ventilated place.

2. If the fabric part is contaminated, please wipe the product surface with a wrung-out wet wipe or a soft cloth.

- Do not use chemical cleaning agents.

3. Please avoid scratching the product surface with sharp objects.

4. After use, please store the product in a safe place and do not place heavy objects on it.

*** Do not store this product in the following locations: **

- Direct sunlight
- High temperature and high humidity places
- Wet places
- Near infants and pets
- Note: No compensation will be provided for injuries caused by ignoring the warning instructions and using the product.

02 Product Information

Item	DC 605 Fabric Desk Chair
Product Name	Fabric Massage Desk Chair
Model Number	BT-21095H
KC Certification No.	R-R-Pio-OC001 (Electromagnetic Compatibility) / YU10003-22005 (Safety Confirmation) / HU10595-22012A (Safety Certification)
Battery Capacity	14.8 Vdc / 5,000 mAh / 74Wh
Rated Voltage	220V, 50/60 Hz / DC 12 V / 3A
Dimensions	68 × 69 × 113 cm
Weight	21 Kg
Material	ABS, Glass-Filled Nylon, Sponge
Manufacturer	Indicated separately on the product
Repair & Exchange Location	Warranty Card
Quality Assurance Standards	Refer to the quality assurance instructions at the bottom of the details page
Components	605 Desk Chair x1, CEHG Charging Cable x1, Adapter x1, User Manual x1, Quality Warranty Card x1

03 Charging Method

Charging Steps

1. When charging the product and battery, if the product is hot, it may cause danger. Please charge it after the product cools down.

2. Please insert the charger plug into the charging port of the device to be charged, or connect it to the adapter for

charging.

3.The indicator light on the charger plug will turn on.

- When the battery is fully charged, the indicator light will change.

LED Indicator Lights (Charging/Completion Prompt)

- Charging: Blue light stays on
- Completed: Red light stays on
- When the battery is fully charged, the blue light turns off.

Battery Charging Precautions

Do not use the product while charging.

- Note: The battery may be hot after using the product. Please charge it after the product cools down.
- This product uses a dedicated charger and plug. Please be sure to use a DC 12V dedicated charger.

Once fully charged, the chair can complete up to 16 operating cycles before recharging is required

WARNING: The USB-C port is intended only for charging the chair's internal battery. Do not use it to charge phones, tablets, laptops, or any other electronic devices. Doing so may result in improper operation or damage.

04 Usage Precautions

- If the product or charging port is wet or has moisture, there may be a risk of short circuit and overheating. Please ensure it is completely dry before use.
- Do not use it in places that are easy to shake or unstable (such as vehicles, ships).
- Be sure to use the DC 12V dedicated adapter when charging.
- Keep children away from this product.
- Do not place the product in high temperature or direct sunlight.
- Do not place other items on the product.
- Do not drop or hit the product.
- The product is not waterproof or moisture-proof. If the product is submerged in water, dampened, or foreign objects enter the interior, it may cause short circuit and overheating. Therefore, do not disassemble the battery or repair it yourself, and please contact the official customer service center immediately.
- Do not use the product while charging.
- If you have wounds, rashes, or other skin conditions, or feel unwell, please suspend use. If you feel abnormal after use, please stop using it immediately.
- This product includes a personal information processing procedure recorded to provide after-sales service.

05 Frequently Asked Questions

- Why does the massage stop suddenly during use?

To protect the user, the massage function will automatically turn off after massaging the same part continuously for 15 minutes.

- Can it be used for a long time on painful areas?

The single automatic operation time is 15 minutes. It is not recommended to use it continuously on painful areas for more than 2 hours.