




DC #375 - Desk Chair Assembly Instructions




Parker Living®
A Division of Parker House




A x1




B x1




C x2




D x1




E x1




F x5




G x1



H x1




I x4



M6X20mm

J x8



M6X35mm




L x4




M x1




STEP 1




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6




STEP 7



STEP 6




FINISHED




Function Description

Lumbar height adjustment




Hold the lumbar pad from behind the chair.
Adjust it up or down to fit your spine's natural curve.

Flip-up Armrests



Lift up to save space or push down to use.



The chair wobbles when you pull out the handle.
There's a circle under the chair if you turn it,
it will lessen the force required to lean back in the chair.