


Assembly Instructions

Callahan Lift Recliner

BEFORE ASSEMBLY

Thank you for purchasing this quality product. This product has been designed for easy assembly and constructed for durability. Please take the time to read and follow the assembly instructions carefully.

Power Lift Recliner with Heat & Massage




Part List

When unpacking, please be careful not to discard any parts with the packaging. Before continuing, please make sure you have the following parts:

No	Description	Sketch	Qty
A	Body		1 PC
B	Back cushion		1 PC
C	LAF Wing		1 PC
D	RAF Wing		1 PC
E	Plug Transformer		1 PC
F	Handheld controllers		1 PC


Step 1

Remove the four screws securing the shipping board by turning them counterclockwise by hand only. Do not use any tools. Keep the four screws for use in Step 2, then remove the shipping board.




Step 2

Using the four screws removed in Step 1, install them into the four threaded holes on the chair base. Turn each screw clockwise by hand until securely tightened.




Step 3

Remove the LAF wing (C), RAF wing (D), transformer (E), and handheld controllers (F) from the bottom of the Body (A). Then carefully return the chair to the upright position and remove the carton and all protective packaging materials for use in the following assembly steps.




Step 4

Install the back cushion (B) into the body (A) by positioning the female metal receiver brackets over the male metal posts. Ensure that the female metal receives brackets on each side line up with the seat metal posts. Push the backrest down until each side is locked into place and an audible "click" is heard.




Step 5

Install the LAF Wing (C) and RAF Wing (D) by sliding wings in a downward motion along the side of the seat back to connect the brackets.




Step 6

When connecting the power cables between the backrest and the chair body for the Headrest Massage, Lumbar, and Heat functions, first identify each cable by its color, connector shape, and label such as "HEADREST/MASSAGE," "LUMBAR," and "HEAT," match each cable with the corresponding port on the chair body according to its label and design, then insert each connector in the correct orientation and press gently until it is fully seated and securely locked.




Step 7

Attach the flap to the seat frame by pulling the flap down, and pressing the bottom under the seat base, connecting the velcro.





Step 8

Connect one end of the power adapter securely to the power input cable located at the lower rear of the chair, ensure the connector is fully inserted and lock the retaining clip firmly to prevent loosening during use, then plug the other end of the power adapter into a wall outlet or a power strip.



Function Display





1. **Lift Chair / Close Footrest** – Press and hold to raise the chair while simultaneously retracting the footrest.
2. **Lower Chair / Open Footrest** – Press and hold to lower the chair while simultaneously extending the footrest.
3. Press **Back Recline** to recline the backrest.
4. Press **Backrest Upright** to return the backrest to the upright position.
5. Press **Headrest Up** to raise the power headrest.
6. Press **Headrest Down** to lower the power headrest.
7. Press **Lumbar Up** to increase the lumbar support.
8. Press **Lumbar Down** to decrease the lumbar support.
9. Press **Heating** to turn the seat heating function on or off.
10. Press **Massage** to turn the vibration massage function on or off.
11. Press **STAND** to return the chair to the home position.